

This procedure for “*Hyundai: Terracan, Amica, Atos, Atoz remote key – Worn out button replacement procedure*” was prepared by Polmex – Western Australian manufacturer of Silicone Button Replacements for remote key controls of various car makes and models: Land Rover, Range Rover, Toyota, Mitsubishi, Kia, Holden, Commodore, Ford, Hyundai, BMW ...and more

For Orders please visit us on line at www.polmex.com.au



Unscrew holding screw located at the back of your remote key.



Separate back part of the cover from the key.



Pull your remote apart as shown on the picture above.



Silicone buttons will be fitted from inside of the remote. Simply press fit silicone buttons in.



Once your silicone buttons are fitted in, place electronic board back in remote, cover it with bottom part of the shell and screw it together. **No reprogramming is need it** as remote will work straight away.



Your remote with fitted in silicone repair buttons will look like the one above.