

This procedure for “*Range Rover P38 Remote key Buttons Replacement* ” was prepared by Polmex – Western Australian supplier of Silicone Button Replacements for remote key controls of various car makes and models: Land Rover, Range Rover, Toyota, Mitsubishi, Kia, Holden, Commodore, Ford, Hyundai, BMW and more

For Orders please visit us on line at [www.polmex.com.au](http://www.polmex.com.au)

**You are replacing broken plastic buttons cover with Silicone Replacement Pad from POLMEX.**

Our pad is made form LSR Silicone and will not deform, change shape and break unlike original plastic cover. It is designed to LAST.



**Tools to use:**  
Stanley knife

**Parts you need:**  
Polmex Silicone Repair Pad



Using Stanley knife, remove old buttons pad from your remote.



Your remote control should look like the one above, ready for fitting new Silicone pad. **DO NOT USE** any lubricants or detergents for cleaning grooves as it will affect firm seating of a pad.



Press fit new pad in, making sure it sits firm and flat in groove all around



**No reprogramming is need it** as remote will work straight away.