

This procedure for “*Hyundai i10,i20, i30, i35,i40 Genesis, Tuscon, Accent Active, SantaFe replacement button pad instructions*’ prepared by Polmex – Western Australian manufacturer of Silicone Button Replacements for remote key controls of various car makes and models: Land Rover, Range Rover,Toyota, Mitsubishi, Kia, Holden, Commodore, Ford, Hyundai, BMW, Nissan, Hyundai and more

For Orders please visit us on line at www.polmex.com.au

You are replacing worn buttons cover in Hyundai flip key with Silicone Repair Pad from POLMEX.

Our pads are made form high purity LSR Silicone and will not: deform, change shape, become brittle and break unlike original cover. It is a great fix at a fraction of the price of new remote and re-programming.



Do Not open remote. Gently remove an old rubber pad from your remote using flat screw driver.



Next you need to remove plastic stiffener still attached to your remote. Use small flat screwdriver to lift it up and detach from remote. It will not be used as new Silicon buttons does not need extra support.



Place a new silicone pad over top part of your remote. Use rolling motion when positioning pad in grooves and press firmly till pad “engages“ with hard shell all around edges. **DO NOT USE** any lubricants or detergents for cleaning grooves as it will affect firm seating of a pad.
No re-programming is required.