

This procedure for “*Autowatch – 4 buttons, alarm immobiliser systems remote key Buttons Replacement* ” was prepared by Polmex – Western Australian manufacturer of Silicone Button Replacements for remote key controls of various car makes and models: Land Rover, Range Rover, Toyota, Mitsubishi, Kia, Holden, Commodore, Ford, Hyundai, BMW and more...


For Orders please visit us on line at [www.polmex.com.au](http://www.polmex.com.au)

You are replacing worn buttons cover in **Autowatch older version of remote fob with Silicone Repair Pad from POLMEX.**


Our pads are made form high purity LSR Silicone and will not: deform, change shape, become brittle and break unlike original cover. It is a great fix at a fraction of the price of new remote and re-programming.




Unscrew 2 small screws at the back of plastic shell. Open remote and separate in 2 parts first: top hard shell part with button key pad and electronic board and second part of hard shell with two batteries.



Next you will separate electronic board from hard shell. Use your finger nail to lift it up.



Gently lift up electronic board from 3 mounting pins. When removing electronic board take care not to misplace small clear light lense. Next use flat screw driver to lift light lense from hard shell or a finger nail.



Once lens is removed remove you can push old key pad out from plastic shell using your thumb.



Your remote is ready for insertion of new Silicone repair pad.



Start with pushing key button thru the key button hole in hard shell and place bottom holes onto respective mounting pins. Once pad is in correct position, you need to install clear light lens. Next place electronic board over key button pad. Holes in top and bottom part of the board have to go onto mounting pins.

Next place part with mounted electronic board over bottom part of shell. Again holes in electronic board have to be mounted have to go onto mounting pins.



If all components are correctly positioned you can close remote by screwing hard shell together.



Your refurbished remote should look like the one in the picture above.  
**No re-programming is needed.**